MAINTENANCE SCHEDULE

THE K-9 KUBE MUST BE MAINTAINED IN ACCORDANCE WITH THE FOLLOWING MAINTENANCE SCHEDULE.

DO VISUAL INSPECTION DAILY.

MAINTENCE AND ANY NECESSARY REPAIRS MUST BE CARRIED OUT BY A SUITABLE COMPETENT PERSON.

CHECK EVERY

FLASHING LIGHTS	BEFORE USE/EVERY 8 HOURS
HYDRAULIC OIL LEVELS	100 HOURS/3 MONTHS
MOTION ALARM	BEFORE USE/EVERY 8 HOURS
HOLD DOWN BOLTS	100 HOURS/3 MONTHS
INTERNAL LIGHT	BEFORE USE/EVERY 8 HOURS

MAINTENANCE NOTES

HYDRAULIC OIL- FUCHS, RENOLIN B PLUS 46